

Z1 NANO 48V TRACK HEAD

6W, REMOTE 48VDC TRACK POWER SUPPLY

designplan®

installation instructions



INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS. READ ALL INSTRUCTIONS. IMPORTANT SAFETY INSTRUCTIONS. SAVE THESE INSTRUCTIONS.

DANGER - RISK OF SHOCK - DISCONNECT POWER BEFORE INSTALLATION! Please read all instructions before installation.

- Keep these instructions for future reference.
- Must be installed by a qualified electrician in accordance with national and local standards. Designplan is not responsible for fixtures installed without regard to these standards.
- Unauthorized alterations or tampering of product voids warranty.
- The main power connection must be in accordance with local electrical codes.
- Suitable for INDOOR applications.



IP40

Maintenance

Scheduled maintenance must be carried out once a year on all lighting devices, regardless of appliance class and type of use. It must include the following operations:

- Periodically clean fixtures to remove dirt from gratings and screw heads.
- Check tightness of screws on various parts of the device.
- Check that all cable glands and cables are intact and tight. Check that the glass or plastic lens is intact, and replace it if broken or damaged.
- The internal components such as the ballast, driver, washers and screws must not show clear signs of oxidation or rust. Clear traces of rust and oxidation will indicate the presence of water inside the device.
- In the case of damage, the components must be replaced by original components or spare parts.


Z1 NANO 48V TRACK HEAD

6W, REMOTE 48VDC TRACK POWER SUPPLY

designplan®

installation instructions

FIXTURE DIMENSIONS:



FIXTURE INSTALLATION:



- No tools are required to install the fixture onto the track.
- The fixture can be secured onto the track by pressing it in gently by hand until you hear a "click". It will remain secured and electrically powered.
- The location of the fixture may easily be changed by pulling it gently to one direction or the other.
- The fixture may be easily removed from the track by pulling it out.