



INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS. READ ALL INSTRUCTIONS. IMPORTANT SAFETY INSTRUCTIONS. SAVE THESE INSTRUCTIONS.

DANGER - RISK OF SHOCK - DISCONNECT POWER BEFORE INSTALLATION! Please read all instructions before installation.

- Keep these instructions for future reference.
- Must be installed by a qualified electrician in accordance with national and local standards. Designplan is not responsible for fixtures installed without regard to these standards.
- Unauthorized alterations or tampering of product voids warranty.
- The main power connection must be in accordance with local electrical codes.
- Suitable for INDOOR applications.
- DO NOT INSTALL INSULATION WITHIN 3.0" (76 mm) OF ANY PART OF THE LUMINAIRE.

**IP20**

Maintenance

Scheduled maintenance must be carried out once a year on all lighting devices, regardless of appliance class and type of use. It must include the following operations:

- Periodically clean fixtures to remove dirt from gratings and screw heads.
- Check tightness of screws on various parts of the device.
- Check that all cable glands and cables are intact and tight. Check that the glass or plastic lens is intact, and replace it if broken or damaged.
- The internal components such as the ballast, driver, washers and screws must not show clear signs of oxidation or rust. Clear traces of rust and oxidation will indicate the presence of water inside the device.
- In the case of damage, the components must be replaced by original components or spare parts.



BICCHIERE TONDO CON BASETTA / RASO MURO



10W MAX (GU10 BULB BY OTHER), 120VAC

installation instructions


FIXTURE DIMENSION:




ASSEMBLY INSTRUCTION

Switch off the mains supply before starting the installation


FIXTURE INSTALLATION



- 1** get off base 'a' and fix it to the wall




- 2** do the wiring with 120V voltage and connect the yellow/green ground wire




Use gel-filled waterproof wire-nuts for wire connections.


- It is the contractor's responsibility to install Remote Driver in a suitable electrical enclosure.



- 3** fix the structure to the base 'a' and insert the bulb to the GU10 lamp holder(Provided by others).




FIXTURE INSTALLATION




1

Drill a hole of $\varnothing 1.38"$ in to the plasterboard and leaving a space of 1.77" for inserting the springs.




2

do the wiring with 120V voltage and connect the yellow/green ground wire



Use gel-filled waterproof wire-nuts for wire connections.

- It is the contractor's responsibility to install Remote Driver in a suitable electrical enclosure.



3

insert the lamp in the plasterboard by means of a suitable spring

