
CASE MAXI / MAXI 20 / MAXI 20 PRO

12W, 30W, 50W, INTEGRAL 120-277VAC



DANGER - RISK OF SHOCK - DISCONNECT POWER BEFORE INSTALLATION! Please read all instructions before installation.

- Keep these instructions for future reference.
- Must be installed by a qualified electrician in accordance with national and local standards. Designplan is not responsible for fixtures installed without regard to these standards.
- Unauthorized alterations or tampering of product voids warranty.
- The main power connection must be in accordance with local electrical codes.
- Suitable for OUTDOOR applications.



MAXI



MAXI 20





designplan@

installation instructions

MAXI 20 PRO

ATTENTION: <u>For Wall/Ceiling</u> - It is the contractor's responsibility to caulk around all the edges between the fixture and the mounting surface to satisfy wet label requirements. Contractor **MUST** use gel-filled wire nuts.

Maintenance

Scheduled maintenance must be carried out once a year on all lighting devices, regardless of appliance class and type of use. It must include the following operations:

- Periodically clean fixtures to remove dirt from gratings and screw heads.
- Check tightness of screws on various parts of the device.
- Check that all cable glands and cables are intact and tight. Check that the glass or plastic lens is intact, and replace it if broken or damaged.
- The internal components such as the ballast, driver, washers and screws must not show clear signs of oxidation or rust. Clear traces of rust and oxidation will indicate the presence of water inside the device.
- In the case of damage, the components must be replaced by original components or spare parts.

CASE MAXI / MAXI 20 / MAXI 20 PRO

12W, 30W, 50W, INTEGRAL 120-277VAC

designplan@

installation instructions

RECOMMENDATIONS

- 1) verify that the equipment used to connect our devices to enjoy
- all the guarantees required under European law;
- 2) use the cables, connectors and quality materials for electrical wiring;
- 3) Products with IP67/68 degree make the wiring / connections with accessories
- provide the same degree IP of the selected product (available in the catalog);

4) In the case of installations outside is not recommended to install the power supplies in the formwork and / or in the junction box without adequate protection;

