



DANGER - RISK OF SHOCK - DISCONNECT POWER BEFORE INSTALLATION! Please read all instructions before installation.

- Keep these instructions for future reference.
- Must be installed by a qualified electrician in accordance with national and local standards. Designplan is not responsible for fixtures installed without regard to these standards.
- Unauthorized alterations or tampering of product voids warranty.
- The main power connection must be in accordance with local electrical codes.
- Suitable for INDOOR applications.
- DO NOT INSTALL INSULATION WITHIN 76 mm (3.0") OF ANY PART OF THE LUMINAIRE.



designplan

installation instructions



Maintenance

Scheduled maintenance must be carried out once a year on all lighting devices, regardless of appliance class and type of use. It must include the following operations:


- Periodically clean fixtures to remove dirt from gratings and screw heads.
- Check tightness of screws on various parts of the device.
- Check that all cable glands and cables are intact and tight. Check that the glass or plastic lens is intact, and replace it if broken or damaged.
- The internal components such as the ballast, driver, washers and screws must not show clear signs of oxidation or rust. Clear traces of rust and oxidation will indicate the presence of water inside the device.
- In the case of damage, the components must be replaced by original components or spare parts.

MOOR

Fixture Installation (In a Gypsum Wall With Optional Plasterkit)

installation instructions

designplan




sales@designplan.com www.designplan.com 79 Trenton Avenue, Frenchtown NJ 08825 © Copyright 2019 Designplan Lighting, Inc. P: 908-996-7710 F: 908-996-7042



Fixture Installation (In a Solid Wall)

installation instructions

designplan@



79 Trenton Avenue, Frenchtown NJ 08825 © Copyright 2019 Designplan Lighting, Inc.