

SPIRIT

120-277VAC

- Must be installed by a qualified electrician in accordance with national and ٠ local standards. Designplan is not responsible for fixtures installed without regard to these standards.
- Unauthorized alterations or tampering of product voids warranty.
- The main power connection must be in accordance with local electrical codes.
- Suitable for INDOOR applications.
- DO NOT INSTALL INSULATION WITHIN 3.0" (76 mm) OF ANY PART OF THE LUMINAIRE.

Maintenance

Scheduled maintenance must be carried out once a year on all lighting devices, regardless of appliance class and type of use. It must include the following operations:

- Periodically clean fixtures to remove dirt from gratings and screw heads. •
- Check tightness of screws on various parts of the device. •
- Check that all cable glands and cables are intact and tight. Check that the glass or plastic lens is intact, and replace it if broken or damaged.
- The internal components such as the ballast, driver, washers and screws must not show clear signs • of oxidation or rust. Clear traces of rust and oxidation will indicate the presence of water inside the device.
- In the case of damage, the components must be replaced by original components or spare parts.

Notes:

- Leave at least 2.0" of free space around the box. Do not cover the box with fiberglass or other kind of material.
- Keep a minimum distance of 20.0" between the fitting and the illuminated object.


P: 908-996-7710 F: 908-996-7042 1 of 3



DANGER - RISK OF SHOCK - DISCONNECT POWER BEFORE INSTALLATION! Please read all instructions before installation.











Fixture Installation





sales@designplan.com www.designplan.com 79 Trenton Avenue, Frenchtown NJ 08825 © Copyright 2018 Designplan Lighting, Inc. P: 908-996-7710 F: 908-996-7042 2 of 3

SPIRIT

designplan@







Orientations:



max 13W