BICCHIERE TONDO PARETE



10W MAX PER BULB, 120VAC

installation instructions



INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS. READ ALL INSTRUCTIONS. IMPORTANT SAFETY INSTRUCTIONS. SAVE THESE INSTRUCTIONS.

DANGER - RISK OF SHOCK - DISCONNECT POWER BEFORE INSTALLATION! Please read all instructions before installation.

- Keep these instructions for future reference.
- Must be installed by a qualified electrician in accordance with national and local standards. Designplan is not responsible for fixtures installed without regard to these standards.
- Unauthorized alterations or tampering of product voids warranty.
- The main power connection must be in accordance with local electrical codes.
- · Suitable for INDOOR applications.





IP20

Maintenance

Scheduled maintenance must be carried out once a year on all lighting devices, regardless of appliance class and type of use. It must include the following operations:

- Periodically clean fixtures to remove dirt from gratings and screw heads.
- · Check tightness of screws on various parts of the device.
- Check that all cable glands and cables are intact and tight. Check that the glass or plastic lens is intact, and replace it if broken or damaged.
- The internal components such as the ballast, driver, washers and screws must not show clear signs
 of oxidation or rust. Clear traces of rust and oxidation will indicate the presence of water inside the
 device.
- In the case of damage, the components must be replaced by original components or spare parts.

P: 908-996-7710 F: 908-996-7042


BICCHIERE TONDO PARETE



10W MAX PER BULB, 120VAC

installation instructions


Fixture Dimensions




INSTALLATION:





All connections must be executed without mains voltage













2. do the wiring with 120V power supply. Connect the yellow/green cable ground wire





Use gel-filled waterproof wire-nuts for wire connections.

It is the contractor's responsibility to install Remote Driver in a suitable electrical enclosure.

3. fix the structure to the brackets and insert the bulbs.