



INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS. READ ALL INSTRUCTIONS. IMPORTANT SAFETY INSTRUCTIONS. SAVE THESE INSTRUCTIONS.

DANGER - RISK OF SHOCK - DISCONNECT POWER BEFORE INSTALLATION! Please read all instructions before installation.

- Keep these instructions for future reference.
- Must be installed by a qualified electrician in accordance with national and local standards. Designplan is not responsible for fixtures installed without regard to these standards.
- The main power connection must be in accordance with local electrical codes.
- Unauthorized alterations or tampering of product voids warranty.
- Suitable for OUTDOOR applications.



Electrical Connections:

- LED lights must be **connected in series** respecting polarities.
- **CHOOSE POWER SUPPLY ACCORDINGLY.** Please consider the voltage through which fixtures are fed as well as the max power consumption.
- **Connect power only if all fixtures are connected.**
- This unit must be used in conjunction with a suitable fountain rated power supply.
- The electronic power supply is current-stable, therefore it partially compensates the voltage-drop problems related to the cable length; we suggest not to exceed 100 ft.
- Use only Class 2 type electronic power supply.
- Never use switches on secondary circuit.

ATTENTION: It is the contractors responsibility to caulk around all the edges between the fixture and the mounting surface, to satisfy wet label requirements.

Maintenance

6FKHGDPDLWHDEHPXWEHFDUULHGRWRBHDHDURQOOLKWLQHYFHVUHDUGOHVVRIDSSOLDEH
FODVVDQWVSHRHXHWPXWLEOBSHWKHIROORZBSHUDWLRQ

‡ 3HULRGLFDOOFDHDQVWHVWRUHPRMGLUWIURPUJWLDQDQVDFUHZHDGV

‡ KHFNWLKWEVVRIVFUHZRQULRXSDUWVRIWKHGHYFH

‡ KHFNWKDWDQOOFDEOHODQVDQFDEOHVDUHLWDFWDQWLKWEHFNWKDWKHOEYVUSODVWLF

intact and replace it if broken or damaged.

The internal components such as the ballast driver, washers and screws must not show clear signs of oxidation or rust. Clear traces of rust and oxidation will indicate the presence of water inside the device.

- In the case of damage, the components must be replaced by original components or spare parts.

